

OPERATION MANUAL

1. IDP ADJUSTMENT

Set the interpupillary distance (IDP) by grasping the body and bending it until you can see one circle of view. The setting for your eyes will be indicated on the IPD Scale.



2. FOCUSING

Close your right eye and sight an object with your left eye. Focus the binocular by rotating the center focus wheel until the image is sharp and clear.

Open your right eye and close your left eye. Rotate the right diopter ring until the object sighted is sharp and clear (Note the setting of the diopter scale for later use.)

Both sides (eyes) are now in focus and you will need to use only the center focus wheel to focus on the other objects.

DIOPTER RING TWIST-UP-EYECUP OCULAR LENS FOCUS RING ORJECTIVE LENS

3. RUBBER TWIST-UP-EYECUPS

Twist down for use with eyeglasses and twist up for use without eyeglasses. They provide comfort and promote viewing ease.

CARE INSTRUCTIONS

- · Store your binocular in a moisture-free area.
- Keep the lens covers (that come with your binocular except compact type) on the tenses when binocular is not in use.
- When wiping the tenses use the lens cloth that comes with the binocular or a soft lintless cloth.
- To remove any remaining dirt or smudges add one or two drops of isopropyl alcohol to the cloth.

CAUTION

Viewing the sun can cause permanent eye damage. Do not view the sun with this binocular or even with the naked eye.

IMPORTANT

Never attempt to clean your binocular internally or try to take it apart.





Manual METOR HD 8x42





WWW.NIKKOSTIRLING.COM

WWW.NIKKOSTIRLING.COM